User Quick Guidelines for iRIS8 Addressable Fire Alarm Panel

## FAULT Events Review in the System

FAULT EVENT Indication

FAULT Message

GENERAL FIRE
PRE ALARM
GENERAL FAULT
SYSTEM FAULT
SOUNDERS SILENCED
DELAY
POWER

DISABLE
TEST
WARNING
FIRE Confirmed
FIRE Output Fault/Disable
PROTECTION Confirmed
PROTECTION Panel Fault

TELETEK
13:22 | 13.07.2021

Battery Loss, Periphery Device 11
1   Tue 13.Jul.2021 08:38:24

0 Alarms
1 Faults
2 Disable

EXIT | MENU | Access 1 | MORE

❶ **FAULT EVENT**
Turn off the buzzer:

TELETEK
13:22 | 13.07.2021
Loop Device Fault, Zone 1, Loop 1, Loop Device Address 1
1   Tue 13.Jul.2021 08:38:24
0 Alarms
1 Faults
2 Disable
EXIT | MENU | Access 1 | MORE

TELETEK
13:22 | 13.07.2021
Silence Alarm | Silence Buzzer | System
0 Alarms
1 Faults
2 Disable
Evacuate | RESET
EXIT | MENU | Access 1 | MORE

In case of Operation in Network, turn off the buzzer as choose:

TELETEK
13:22 | 13.07.2021
1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16 17 18 19 20
21 22 23 24 25 26 27 28 29 30
31 32 33 34 35 36 37 38 39 40
41 42 43 44 45 46 47 48 49 50
51 52 53 54 55 56 57 58 59 60
61 62 63 64
0 Alarms
1 Faults
2 Disable
ALL | THIS
EXIT | MENU | Access 1 | MORE

Select Panel Number 1-64, press an active button for a single panel in the Network,

or

Select ALL available panels in the Network,

or

Select only THIS concrete panel.

Check the type of FAULT!

TELETEK
13:22 | 13.07.2021
0 Alarms
1 Faults

TELETEK
13:22 | 13.07.2021
Loop Device Fault, Zone 1, Loop 1, Loop Device Address 1
1   Tue 13.Jul.2021 08:38:24
0 Alarms
1 Faults

☞ ❷

WARNING Events Review in the System

NOTE: The WARNING Messages for events are with lower priority and they are not displayed automatically from the panel!

WARNING EVENT Indication

GENERAL FIRE
PRE ALARM
GENERAL FAULT
SYSTEM FAULT
SOUNDERS SILENCED
DELAY
POWER

DISABLE
TEST
WARNING
FIRE Confirmed
FIRE Output Fault/Disable
PROTECTION Confirmed
PROTECTION Panel Fault

TELETEK
13:22 | 13.07.2021
Silence Alarm | Silence Buzzer | System
0 Alarms
1 Faults
1 Warnings
Evacuate | RESET
EXIT | MENU | Access 1 | MORE

❶ **WARNING EVENT**
Turn off the buzzer:

TELETEK
13:22 | 13.07.2021
Silence Alarm | Silence Buzzer | System
0 Alarms
1 Faults
1 Warnings
Evacuate | RESET
EXIT | MENU | Access 1 | MORE

TELETEK
13:22 | 13.07.2021
1 2 3 4 5 6 7 8 9 10
11 12 13 14 15 16 17 18 19 20
21 22 23 24 25 26 27 28 29 30
31 32 33 34 35 36 37 38 39 40
41 42 43 44 45 46 47 48 49 50
51 52 53 54 55 56 57 58 59 60
61 62 63 64
0 Alarms
1 Faults
1 Warnings
ALL | THIS
EXIT | MENU | Access 1 | MORE

In case of Operation in Network, choose the panels, where to perform Turn off Buzzer.

Check the type of WARNING!

TELETEK
13:22 | 13.07.2021
0 Alarms
1 Faults
1 Warnings

TELETEK
13:22 | 13.07.2021
Clean me now, Zone 1, Loop 1, Loop Device Address 2, Smoke Detector 2
1   Tue 13.Jul.2021 09:20:47
0 Alarms
1 Faults
1 Warnings

☞ ❷

❷ **Call the MAINTENANCE SERVICE and report for the type of FAULT or WARNING event:**

☞ ☎
Tel.:...
Mobile:...
Responsible person:..